

Car Multimedia Player

User Manual

CAR ENTERTAINMENT SYSTEM

CAR AUDIO VIDEONAVIGATION


XM-2D6911
XM-2DN6909



CONTENTS

Remote control	01
Key Function	02
Program function	03
Features	04
1. Disc Player	04
2. USB/SD Player	05
3. MP3 Player	06
5. TV Player	08
6. Radio Player	09
7. AV-in	10
8. F-CAM	10
Setting	11
1. system setup	11
2. Audio setup	11
3. Display setup	12
4. Media setup	12
5. BT setup	12
6. Time setting	13
Optional functions	14
1. Mirror Link	14
Fault diagnosis	16
A.Common troblshooting guide	16
A.About this manual	17

Remote control



ITEM	KEY NAME OR GRAPHICS	KEY FUNCTION DESCRIPTION
①		short press into play,after play, short press for Mute, long press into off
②		key for disk out
③	MENU	Return to main menu
④	EQ	Frequency response equalizer
⑤	ST	Radio/mono ,selection
⑥	AMS	Auto scan and preview station
⑦	SEL	Audio regulation
⑧	VOL-/+	Volume adjustment

ITEM	KEY NAME OR GRAPHICS	KEY FUNCTION DESCRIPTION
⑨		Play/Pause
⑩		short press into last and next song selection, long press into fast forward /backward
⑪	Direction Key	Up/down/left/right arrow
⑫		Short press into BT or receive phone, long press into BAND switch
⑬		short press for hung up phone, long press into MODE conversion
⑭		short press number 1 into channel selection and song selection, long press into OSD
⑮		Short press number 2 into channel selection and song selection, long press into AUDIO conversion
⑯		short press number 3 into channel selection or song selection, long press into ANGLE selection
⑰		Short press number 4 into channel selection or song selection, long press into GOTO
⑱		Short press number 5 for channel selection or song selection long press into RPT for Single/Folder/All
⑲		short press number 6 for channel selection or song selection, long press into random play
⑳		short press number 7 into channel selection and song selection, long press into SUB-T
㉑		short press number 8 into channel selection and song selection, long press into ZOOM play
㉒		short press number 9 into channel selection and song selection, long press into TITLE play
㉓		short press*(BT is ok), long press into SETUP
㉔		short press number 0 into channel selection and song selection, long press into LOUD
㉕	# SLOW button icon"/>	Short press #(BT is ok), slow play

1.1 the user instructions

- (1). For your safety, do not watch the video or frequent operation during driving host. Please put the volume down as much as possible, lest affect safe driving, and abide by traffic regulations.
- (2). GPS (global positioning system) in building concentration areas, under the viaduct, used in bad weather conditions, the affect of GPS signal, which can lead to inaccurate positioning. Please refer to our actual road at this time.
- (3). Because some roads and facilities will be constantly updated, please use genuine software and update the map data.
- (4). Please cherish your product. Into the plate mouth, SD card slot must be kept clean, not to the entrance to the foreign body, lest affect discs and normal SD card read.
- (5). This product is only applicable to the 12V power supply system of auto installation, please don't directly installed in 24V power supply truck or bus, or you will burn out the internal components.
- (6). Please follow the manual and follow the operating rules of related hardware devices and requirements, otherwise it will cause abnormal system operation. If there is a system work abnormal please press the RESET button to restart the system.
- (7). If you need to upgrade and consulting, please contact the local dealer.
- (8). Hope this product can bring convenience for your travel experience.

1.2 products basic information

- (1) hardware: the product adopts sunplus, ST, NXP high-tech enterprise production of IC as main control IC.
- (2) main functions:
 The disc playback: support DVD_R discs, such as VCD, SVCD, CD format
 Supported image formats: JPG, JPE, JPEG, BMP format, etc
 Support audio format: MP3, AC3, TSA, OGG, FLAC, MPA, AAC etc
 Support the video formats: MP4, 3 gp, RMVB, AVI, WMV, FLV, format, etc
 BT, wireless, BT hands-free headset, music playback, make and receive calls
 Radio: the Radio function (partial models with RDS), built-in an AM/FM band
 GPS: support voice navigation, built-in GPS navigation map function of real support before the camera, heavy bass, after reversing visual function
 Function description:

1.3 panel ports and buttons

-  Power key/short press boot, short press to turn it off.  read disc/USB/SD short by a long press fast rewind
-  Read disc/USB/SD short press, song long press fast forward  read dish/USB/SD short press to play pause
-  disc pop up **MENU**: MENU Function **BAND** radio BAND conversion  Mute button
- VOL + / -** volume/the volume **IR**: infrared remote control receiver mouth

Note: according to different suppliers, the panel may be slightly different, please give priority to with actual prod

Radio Mode:

Click to enter the user radio interface, see the interface description.

DISC Mode:

Click to enter the user play interface, see the interface description, Disc player.

USB Mode:

Click to enter the user play interface, see the interface description

SD card Mode:

Click to enter the user play interface, see the interface description

Audio and video input Mode:

click to enter the external audio and video input interface, see the interface description.

TV Mode:

Click to enter the interface, see the interface description.

BT phone Mode:

Click to enter the BT interface, see the interface description

Mirror Link

click to enter the Mirror Link interface, see the interface description

GPS navigation Mode:

click to enter the GPS interface, see the navigation interface description.

System setting Mode:

Click to enter the setting interface. For details, see the interface description

Rear view Mode:


Click to enter the external video mode. For details, see the interface description.

Wallpaper Mode:

click to enter, choose different wallpapers.


1. Disc Player

Support DVD/VCD/CD/DIVX/MP5/MP4/MP3 and other types of disc formats.




2. USB/SD Player



Support DVD/VCD/CD/DIVX/MP5/MP4/MP3 and other types player





3. MP3 Player





4. BT Player






5. TV Player



6. Radio Player




FM radio, 87.50 -108 (China), different bands corresponding to different stations.
 Fine-tuning FM radio frequency scale, represent the frequency of the current work area, the position of the cursor position for the current frequency

Notes

The appearance of the radio UI may differ from the unit, but the function icons are the same. Please forgive us for not being able to inform in advance!

7. AV-in


The machine supports external video signal and input of two audio signals. When the vehicle has other multimedia equipment, the audio and video output signal can be connected to the audio & video input port.



Note

If the system fails to detect external audio or video signal input, the screen will display the prompt: "No Video Signal".

8. F-CAM




1. system setup



- Sets the national range area
- Sets Language
- Front camera switch
- Rear camera switch
- Headlight detection

2. Audio setup



Can switch to different audio playback modes, classic/jazz /live/popular, etc.

loudness control switch




Control the sound source position, support high - school bass adjustment.



Can imitate concert hall, church, soft, three-dimensional scene of a variety of sound.


3. Display setup



Adjust the display style

The contrast, saturation and sharpness of the screen display can be set accordingly.

4. Media setup



Audio Language setting

Subtitle Language setting

Menu Language setting


Change the viewing level password

Modify viewing level

The factory setting password is "123456"

5. BT setup

Open the BT icon and choose how to set the BT name and connect via your phone. BT default password is "0000"



BT Switch


BT name modification

BT name modification

BT password change

Automatic answer connection switch

6. Time setting



The date of the system can be set.

Time zone displays are set for 12 and 24 hours.

Set the hours/minutes/seconds.

7. Further settings




To view more settings, move the left toolbar up.

1.Mirror Link

Connection Process

First, enter the settings, find the "developer options", different mobile phones, their location is not the same, some mobile phones this item is hidden, you need to enter the "on the phone"consecutively click on the "version number" more than 5 times, it will appear " You are in developer mode and do not need to do this, as shown in the following image



The "developer options" that are open, as shown below. After entering the "Developer Options", open the "Developer Options" switch and the "USB Debug" switch, as shown below.



After the above settings are completed, connect to the host through the USB cable, and the host enters the mobile phone interconnection mode (as shown below)

Connect your phone

Into the mobile phone interconnection mode, the first to see the interface;
 Tip 1 Turn on the phone USB debugging
 Tip 2 Connect the USB cable
 Show "detect Andrews phone" "exit" "help" three buttons.



If the icon does not appear, it is recommended to check the following steps:
 1. Is the mobile phone Android version 5.0 and above?
 2. Does the phone's other security application block the installation?
 3. Follow step 3 to re-download and try again.
 4. Reconnect the mobile phone and the host, and the host enters the mobile phone mode (as shown below)

Similarly, the option is checked and allowed, the image starts to be transmitted and displayed on the host. If there is a slow response, please wait a few seconds for normal use.



A. Common troubleshooting guide.

Problem	Cause	Solution
General		
Unit can not power on	Broken unit fuse	Install new fuse with correct rating
	Broke car battery fuse	Install new fuse with correct rating
	Illegal operation	Reset the unit
No/low audio output	Improper audio output connection	Check wiring and correct
	Volume set too low	Increase volume level
	Speakers damaged	Replace speakers
	Heavily biased volume balance	Adjust the channel balance to center position
	Speaker wiring is in contact with metal part of car	Insulate all speaker wiring connections
Poor sound quality or distortion	Pirated disc is in use	Use original disc
	Speaker power rating does not match unit	Replace speakers
	Wrong connections	Check wiring and correct
	Speaker short-circuit	Check wiring and correct
Tel-Mute malfunction	MUTE wire is grounded	Check the 'MUTE' wiring and correct
Unit resets itself when engine is off	Incorrect connection between ACC and BATT	Check wiring and correct
TFT monitor		
Warning information is shown at all times	Parking break wiring is not correct	Check wiring and correct
Flashing image or interference appears on screen	The color system of DVD disc does not match the monitor	Adjust the color system of the DVD disc playing back or the monitor in use
	Pirated disc is in use	Use original disc
	Video cable damaged	Replace cables
	Improper video signal connections	Check wiring and correct
Disc playback		
Cannot insert disc	A disc is already inside the unit	Eject current disc and insert new one
Disc does not play back	Disc is warped or scratched	Use disc in good condition
	Disc is dirty or wet	Clean disc with soft cloth
	Incompatible disc is used	Use compatible disc
	Disc is inserted upside down	Insert disc with label side up
	Disc region code is not compatible with unit	Use disc with proper region code
PBC cannot be used during VCD playback	PBC is not available on the disc	Use disc with PBC available
Repeat or search function is invalid during VCD playback	PBC is on	Turn PBC off
Error messages		
No disc	Disc is dirty	Clean disc with soft cloth
	Disc is upside down	Insert disc with label side up
	No disc inside	Insert disc
Bad disc	Disc is dirty	Clean disc with soft cloth
	Disc is upside down	Insert disc with label side up
Unknown disc	Disc format is not compatible with this unit	Use disc with compatible format
Region Error	DVD region code is not compatible with this unit	Use disc with compatible region code

B. About this manual.

The machine has a series of advanced features, to ensure efficient and receive operation, so these features are designed to simplify the operation, but there is a multi-functional did not say. This manual will help you understand the product performance and operation.

This manual mainly introduces the remote control and touch screen, there are some related functions can only be launched by the remote control and touch screen operation, there are certain functions can be realized by the host